User Instructions (EN)

Product Description:

Product Name: Glass pictureManufacturer: ARTTOR

Country of Manufacture: Poland / Europe

• Model: GAC40x40

Product Dimensions: 40cm x 40cm x 1,1cm (15,75" x 15,75" x 0,43")

• Product Weight: 1,8 kg

• Construction: During production, safe, odorless, and durable inks with deep color saturation are used. The glass picture is made of 4mm thick glass. The edges of the glass have a matte trapezoidal grind. Each picture comes with a mounted hanger and foam spacers that ensure an even distance from the wall.

Contents:

- 1 x Glass picture
- 1 x Installation Instructions


All corners of the picture are protected with plastic covers. The entire picture is protected by bubble wrap or PE foam and then packed in a cardboard box.

Usage Recommendations:

- Regularly check the condition of the mountings and hangers to ensure that the picture is securely hung.
- If the picture requires cleaning, use only a soft, dry cloth to avoid damaging its surface. Do not use rough or abrasive materials for cleaning the picture. When cleaning, gently wipe the surface in one direction, avoiding circular motions. Do not scrub or rub hard to avoid surface damage.
- The picture should be hung as intended: On dry and stable surfaces, in places not exposed to drafts, high humidity, high temperatures, direct sunlight, or near devices and appliances that emit heat.

Technical and Post-Purchase Support:

In case of questions, doubts, issues, or any topics related to the use and installation of the product, contact the seller or the manufacturer directly.





1,8 kg

Warnings and Precautions:

 Before beginning installation, ensure that you have the appropriate tools and are capable of carrying out the installation independently or with the help of an experienced person.

Exercise caution when drilling holes to avoid damaging any electrical, plumbing, or other installations.

Manufacturer's Warranty:

- The manufacturer makes every effort to deliver a high-quality product to customers.
- The manufacturer provides the buyer with a 2-year warranty from the date of purchase.
- Under the warranty, the manufacturer is obligated to repair all defects resulting from manufacturing or material faults.

The manufacturer is not responsible for defects resulting from:

- Modifications or changes to any components
- Incorrect installation, use, or maintenance not in accordance with the instructions and intended purpose
- Mechanical damage during use



Keep away from heat sources, in places not above or in direct proximity to appliances and equipment emitting heat. The product should be placed in locations not exposed to drafts.



Warning, use the product as intended. The product is not a toy, and it may contain small, protruding parts. Keep away from children.



The materials used for packaging are made from recyclable materials in compliance with national environmental regulations.



The inks used during production meet environmental and health certifications, making the product safe for indoor use.



The product contains glass elements.



Do not place the product near flammable materials.



Do not store in areas exposed to high humidity.



Manufacturer: Arttor Waldemar Błahyj i Leszek Błahyj Spółka Cywilna Gostkowo 19, 87-148 Łysomice, POLAND, NIP: PL8792621436, Regon: 340731016

e-mail: biuro@arttor.pl

Installation Instructions (EN)

Familiarize yourself fully with the installation instructions before proceeding. Warning! If you have any doubts or questions, contact the manufacturer to ensure that the installation process is safe and correct.

Safety Measures:

- Always wear protective gloves to protect your hands during installation.
- Wear protective goggles to safeguard your eyes from any possible splinters.
- Before beginning installation, ensure that the chosen location is safe and checked for technical stability. Ensure that installation work does not interfere with any structural, plumbing, or electrical infrastructure of the wall, room, or building. We are not responsible for the choice of the installation site.
- We are not responsible for damages caused by the installer during installation.
- The picture can only be hung using the provided hanger. We are not responsible for other methods of hanging, such as strings, adhesive tapes, or other non-standard solutions. If you use other hanging methods than the manufacturer's standard hanger, responsibility lies with the installer.

Unpacking the Product:

Carefully remove the picture from the packaging by opening the box at the locations where the staples are. Gently slide the picture out of the box and place it on a stable, dry surface. Then remove the protective tape and carefully unroll the protective film to release the product. Thoroughly check the product to ensure that the picture has no damages or defects. Leave the plastic corner protectors on during the hanging process to prevent chipping or breaking the corners during installation. If you notice any irregularities, contact the supplier and seller before further use. Remember not to use force or sharp tools during unpacking to avoid damaging the product.

Tool Preparation:

Prepare a screwdriver, measuring tape, level, pencil, screws, or other chosen mounting systems. The manufacturer recommends using hooks as the safest solution for securing the picture to the wall.

Choosing a Location:

Choose an appropriate location for the picture, ensuring it is clearly visible and adequately lit. Ensure that the wall material where you plan to hang the picture is strong enough to support its weight (the weight is provided in the product description).

Wall Surface Preparation:

The wall surface should be dry, smooth, and even. Ensure that there are no contaminants or debris that could affect the stability of the installation.

Marking the Location:

For pictures with more than one hanger, use a level to mark the place where the picture will be hung. Determine the appropriate height (usually at eye level).

Drilling the Hole and Installing the Screw or Hook:

Drill the hole following the previously described safety measures and the information contained in the installation instructions. Remember that the responsibility for properly creating the hole and mounting the hooks lies with the installer. We are not responsible for improperly performed work in this regard, so we recommend particular caution and accuracy.

Picture Installation:

The glass picture is equipped with a mounted hanger that allows easy and safe hanging on the previously prepared hook. Make sure that the hooks are adequately selected for the weight of the picture and firmly secured in the wall to ensure safety and stability. We are not responsible for improperly prepared hooks, holes, or other hanging systems, nor for inadequate surfaces where the picture is hung. After correctly and finally placing the picture, remove the protective plastic corner guards located at the edges of the picture.

Important: Ensure that the picture is mounted **parallel to the wall.** Proper installation ensures stability and aesthetic appearance. The picture should not tilt or be uneven relative to the wall surface.



Leveling Tips:

Use a level to ensure that the picture is hanging straight.

Responsibility:

The installer should have knowledge of how to use tools. Installation is done at the installer's own risk. If the installer lacks experience, they should consult with someone who can assist safely with the product installation.

Safety Information



The manufacturer, Arttor Waldemar Błahyj i Leszek Błahyj Spółka Cywilna, informs that the manufactured product meets all safety requirements. The materials used in production are free from harmful substances and have been tested and certified in accordance with applicable standards, ensuring safe use under general safety regulations. Arttor has designated Mr. Leszek Błahyj as the contact person for product-related matters. For additional information or to ask questions, please contact us via email: biuro@arttor.pl.



Manufacturer: Arttor Waldemar Błahyj i Leszek Błahyj Spółka Cywilna Gostkowo 19, 87-148 Łysomice, POLAND, NIP: PL8792621436, Regon: 340731016

e-mail: biuro@arttor.pl